
Strap Winch Installation and Operators Instruction Manual



Installation and Operators Manual

Contact your nearby Chore-Time distributor or representative for additional parts and information.

CTB, Inc.

PO Box 2000

Milford, Indiana 46542-2000 USA Phone (574) 658-4101 Fax (877) 730-8825

Email: choretime@choretime.com
Internet: www.choretime.com

October 2020 MV2434K

Limited Warranty Strap Winch

Limited Warranty

LIMITED WARRANTY

Chore-Time Group, a division of CTB, Inc. ("Chore-Time") warrants the new CHORE-TIME Strap Winch manufactured by Chore-Time to be free from defects in material or workmanship under normal usage and conditions, for One (1) year from the date of installation by the original purchaser ("Warranty"). Chore-Time provides for an extension of the aforementioned Warranty period ("Extended Warranty Period") with respect to certain Product parts. If such a defect is determined by Chore-Time to exist within the applicable period, Chore-Time will, at its option, (a) repair the Product or Component Part free of charge, F.O.B. the factory of manufacture or (b) replace the Product or Component Part free of charge, F.O.B. the factory of manufacture. This Warranty is not transferable, and applies only to the original purchaser of the Product.

CONDITIONS AND LIMITATIONS

THIS WARRANTY CONSTITUTES CHORE-TIME'S ENTIRE AND SOLE WARRANTY AND CHORE-TIME EXPRESSLY DISCLAIMS ANY AND ALL OTHER WARRANTIES, INCLUDING, BUT NOT LIMITED TO, EXPRESS AND IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES AS TO MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSES. CHORE-TIME shall not be liable for any direct, indirect, incidental, consequential or special damages which any purchaser may suffer or claim to suffer as a result of any defect in the Product. Consequential or Special Damages as used herein include, but are not limited to, lost or damaged products or goods, costs of transportation, lost sales, lost orders, lost income, increased overhead, labor and incidental costs, and operational inefficiencies. Some jurisdictions prohibit limitations on implied warranties and/or the exclusion or limitation of such damages, so these limitations and exclusions may not apply to you. This warranty gives the original purchaser specific legal rights. You may also have other rights based upon your specific jurisdiction.

Compliance with federal, state and local rules which apply to the location, installation and use of the Product are the responsibility of the original purchaser, and CHORE-TIME shall not be liable for any damages which may result from non-compliance with such rules.

The following circumstances shall render this Warranty void:

- · Modifications made to the Product not specifically delineated in the Product manual.
- Product not installed and/or operated in accordance with the instructions published by the CHORE-TIME.
- · All components of the Product are not original equipment supplied by CHORE-TIME.
- · Product was not purchased from and/or installed by a CHORE-TIME authorized distributor or certified representative.
- Product experienced malfunction or failure resulting from misuse, abuse, mismanagement, negligence, alteration, accident, or lack of proper maintenance, or from lightning strikes, electrical power surges or interruption of electricity.
- · Product experienced corrosion, material deterioration and/or equipment malfunction caused by or consistent with the application of chemicals, minerals, sediments or other foreign elements.
- Product was used for any purpose other than for the care of poultry and livestock.

The Warranty and Extended Warranty may only be modified in writing by an officer of CHORE-TIME. CHORE-TIME shall have no obligation or responsibility for any representations or warranties made by or on behalf of any distributor, dealer, agent or certified representative.

Effective: April 2014

Contents

Topic I	Page
Limited Warranty	2
Safety and General Information Follow Safety Instructions Decal Descriptions DANGER: Moving Parts DANGER: Electrical Hazard	4 4 4
General Information	5
Specifications	5
Assembly	6
Installation	8
Mounting Bracket Installation Wall Mount Bracket Installation Ceiling Mount Bracket Installation Attaching Winch to Mounting Bracket Wall Mount Ceiling Mount	8 9 10 10
Installing Breather Plug	
Wiring	11
Setup. Winch Board Switches and LED's. Local Operation. Setting Travel Limits "Out" Limit "IN" limit. Proper Winch Cabling	13 13 14 14
Maintenance	. 16
Strap Replacement Oil Recommendation	16
Parts Listing	. 18
Kite	10

Safety and General Information

Caution, Warning and Danger Decals have been placed on the equipment to warn of potentially dangerous situations. Care should be taken to keep this information intact and easy to read at all times. Replace missing or damaged safety decals immediately.

Safety-Alert Symbol



This is a safety–alert symbol. When you see this symbol on your equipment, be alert to the potential for personal injury. This equipment is designed to be installed and operated as safely as possible...however, hazards do exist.

Understanding Signal Words

Signal words are used in conjunction with the safety–alert symbol to identify the severity of the warning.



DANGER indicates an imminently hazardous situation which, if not avoided, **WILL** result in death or serious injury.



WARNING indicates a potentially hazardous situation which, if not avoided, **COULD** result in death or serious injury.



CAUTION indicates a hazardous situation which, if not avoided, MAY result in minor or moderate injury.

Follow Safety Instructions

Carefully read all safety messages in this manual and on your equipment safety signs. Follow recommended precautions and safe operating practices.


Keep safety signs in good condition. Replace missing or damaged safety signs.

Decal Descriptions

DANGER: Moving Parts

Disconnect electrical power before working on system, equipment may start automatically. Otherwise personal injury will result.

Severe personal injury will result if the equipment is operated without covers properly installed.



DANGER: Electrical Hazard

Disconnect electrical power before inspecting or servicing equipment unless maintenance instructions specifically state otherwise.

Ground all electrical equipment for safety.

All electrical wiring must be done by a qualified electrician in accordance with local and national electric codes.

Ground all non-current carrying metal parts to guard against electrical shock.

Electrical disconnects and over current protection are not supplied with the equipment.



Strap Winch General Information

General Information

The Chore-Time Ventilation Strap Winch is designed to raise and lower, and/or actuate Ventilation Equipment in a Poultry House . Using the equipment for purposes other than specified in this manual may cause personal injury and/or damage to the equipment.

Specifications

Strap Winch Travel Speed- The Strap Winch travels between 8"-12-1/2" [20.3cm-31.8cm] per minute.

Winch Capacity- The Strap Winch has a working load capacity of 2000 lbs. [907.2 kg] working load.

Pull Direction- The Strap Winch is designed to be centered within the winching load and pull both directions to lift and lower from center.

Pull Distance- The Strap Winch is capable of pulling 6' [1.83m] in both directions.

Assembly Strap Winch

Assembly

Attaching the Winch Mounting Bracket




Figure 1.Winch Mounting Bracket

Motor Installation





Figure 2.Motor Installation

Wiring Motor to the Winch Unit

Wire the Motor to the Winch Unit using the Cord Assembly (4999-119) included as shown below.




Installation

Mounting Bracket Installation

Wall Mount Bracket Installation


Chore-Time Recommends mounting the Strap Winch to a Board that spans at least three Wall Studs. At least two of the Lag Screws (54428) used to attach the Winch should be secured to a Wall Stud. See **Figure 4.** for attaching the Wall Mount Bracket.



Strap Winch Installation

Ceiling Mount Bracket Installation

Chore-Time Recommends mounting the Strap Winch to a Board that spans at least three Rafters (Wood Rafters) or two Rafters (Metal Studs). At least two of the Lag Screws (54428) used to attach the Winch should be secured to a Rafter. **See Figure 5.** below for attaching the Ceiling Mount Bracket.







Figure 5.Ceiling Mounting Bracket

Installation Strap Winch

Attaching Winch to Mounting Bracket

Wall Mount



(8917) 1/2 -13 Hx Lock Nut

Figure 6.Attaching Winch to Wall Mount Bracket

Ceiling Mount




Figure 7. Attaching Winch to Ceiling Mount Bracket

Installing Breather Plug




Figure 8.Installing Breather Plug

Strap Winch Wiring

Wiring

Wiring to Power

See "Wiring Motor to the Winch Unit" on page 7 for Motor Wiring...

- 1.If Wired as shown the "OUT" command signal will cause the strap to extend. An "IN" signal will retract the strap. (Red wire #7 terminal, and Black wire #8 terminal)
- 2. If you want the "OUT" command signal to retract the strap, reverse the red and black wires. (Red wire #8 terminal, and Black wire #7 terminal)







Figure 9.Attaching Winch to Wall Mount Bracket

Wiring 2 Strap Winches in Parallel (To prevent back-feed between Strap Winches)



Strap Winch

Setup

Winch Board Switches and LED's

Local Operation


Strap "Out" rotation

- 1. Switch to the "Local" position.
- 2. For Strap "OUT" rotation press switch OUT/OFF/IN Switch to the "OUT" position.
- 3. For stopping rotation press the "OUT" Limit Switch.
- 4. If the "OUT" Safety Switch is activated, the Winch will stop all operation.

Strap "IN" rotation

- 1. For Strap "IN" rotation, press the IN/OFF/OUT switch to the "IN" position.
- 2. To stop rotation press the "IN" Limit Switch.
- 3. If the "IN" Safety Switch is activated, the Winch will stop.

To reverse Rotation see "Wiring to Power" on page 11



Remote/Local Switch

Remote-Used if connecting to an external Control.

Local-For operating with Winch with the OUT/OFF/IN switch

OUT/OFF/IN Switch -

OUT-To operate the Winch letting Strap out.

OFF-Will not allow any operation.

2434-022 03/2014

IN-To operate the Winch pulling Strap in




Figure 10. Wiring Winch Board Switches and LED's

Setup Strap Winch

Setting Travel Limits

"Out" Limit

- 1. Set the Local/Remote Switch to Local.
- 2. Use the "Out" switch to let out the desired length of Strap. (If needed, Pull up on the Spring Clip and move the "Out" Brass Nut to gain enough travel.
- 3. With the Strap in the desired location, move the "Out" Brass Nut out until it activates the "Out" Limit Switch. (The "LO" LED will illuminate)

Note: If the "OUT" Safety Switch is activated the Winch will stop operation. (The "OT" LED will illuminate)

4. Snap the Spring Clip back into the slot in the Brass Nut.


"IN" limit

1. Use the "IN" Switch to Retract the Strap to the desired length and adjust the "IN" Brass Nut until it depresses the "IN" Limit Switch. (The "LC" LED will illuminate.

Note: If the "IN" Safety Switch is activated the Winch will stop operation. (The "CL" LED will illuminate)


"Out" Spring Clip—
"Out" Brass Nut—
"IN" Brass Nut—

2434-023 03/2014



2. Snap the Spring Clip back into the slot in the Brass Nut.

Caution! Always replace covers on Winch Controls after adjusting or servicing. Failure to replace covers could result in moisture or dust entering, causing damage to the Circuit Boards and/or their Components.



Strap Winch Setup

Proper Winch Cabling





Figure 9.Proper Cabling

Maintenance Strap Winch


Maintenance

Strap Replacement

1. Remove the old Strap as shown below.



2. Route new Strap, re-assemble, and re-attach Drum.




Oil Recommendation

Use: Mobil Glycoil 30, Shell-Tivela 220, Texaco-Synoil, SG-XP220, Esso-S220, Telesia Oil 150, BP-Energol SG -XP 220 Synthetic Oil.

Strap Winch Maintenance

This page left blank intentionally.....



			54421-1	54421-2
			Wall Mount	Ceiling Mount
Item	Description	Qty.	Part No.	
1	Strap Winch	1	53882	53882
2	Motor .33H 1-60/50-220/230 BHD	1	56463	56463
3	Wall Mount Bracket	1	54418	
	Ceiling Mount Bracket	1		54419
4	1/2-13 x 1 HH5 Bolt	3	4415-1	4415-1
5	1/2-13 HX Lock Nut	3	8917	8917
6	3/8 x 3" Lag Bolt	4	54428	54428
7**	3/8-16 x 3/4" HH5 Bolt	10	2182	2182
8**	Strap Winch Gear Case Bracket	1	54420	54420
9	Cord	1	4999-119	4999-119
10*	M10 x 45 Socket Head Screw	1	54841	54841

			54421-1	54421-2
			Wall Mount	Ceiling Mount
Item	m Description Qty.		Part No.	
11*	M10 x 80 Hex Grade Bolt	2	54839	54839
12*	Prevailing Torque M10 Nut	2	54840	54840
13*	Drum Disc	2	54837	54837
14*	Winch Drum Base	1	54838	54838
15*	Winch Strap	1	54919	54919
16**	Spring Lever Assembly	1	54866	54866
17**	Strap Winch Circuit Board	1	54836	54836
18**	3/8 x .875 x .079 Flat Washer	4	546	546
19**	PCB Support Rail	1	55700	55700
20**	M4 x 8 Soc. Hd. Screw	2	55699	55699
21**	1/2-20 UNF Breather Plug	1	56415	56415
22	1/2" Liquid Tight Connector	1	23779	23779
23	1/2" Conduit Lock	1	3357	3357
*Included in 54842 Drum Assembly				

^{*}Included in 54842 Drum Assembly
**In Strap Winch Assembly 53882

Kits

Winch with Motor (54979)

Description	Qty	Part No.
Ventilation Strap Winch	1	53882
230V, 50/60HZ C Face Motor	1	56463
Motor Mount Hardware Kit	1	54921

Wall Mount Kit (54426)

Description	Qty	Part No.
Wall Mount Bracket	1	54418
1/2-13x1 Bolt	3	4415-1
1/2-13 Hx Lock Nut	3	8917
3/8 x 3" Lag Bolt	4	54428

Ceiling Mount Kit (54425)

Description	Qty	Part No.
Ceiling Mount Bracket	1	54419
1/2-13x1 Bolt	3	4415-1
1/2-13 Hx Lock Nut	3	8917
3/8 x 3" Lag Bolt	4	54428



MADE TO WORK.

BUILT TO LAST.®

Revisions to this Manual

Page No.	Description of Change	ECO
19	Updated Parts List	34942
7	Wiring Colors and numbers change	

For additional parts and information, contact your nearest Chore-Time distributor or representative. Find your nearest distributor at: www.choretime.com/contacts

CTB, Inc. PO Box 2000

Milford, Indiana 46542-2000 USA Phone (574) 658-4101 Fax (877) 730-8825

Email: choretime@choretime.com Internet: www.choretime.com